



| System information |   |
|--------------------|---|
| Name               | m0n0wall.local                                |
| Version            | 1.11<br>built on Thu Nov 11 23:02:41 CET 2004 |
| Platform           | wrap  |
| Uptime             | 04:45   |

Interfaces: Assign network ports

**!** The changes have been saved. You must reboot your firewall for changes to take effect.

Interface assignments VLANs

| Interface | Network port             |
|-----------|--------------------------|
| LAN       | sis0 (00:0d:b9:00:d9:24) |
| WAN       | sis1 (00:0d:b9:00:d9:25) |

**+** < Interface hinzufügen

**Save**

**Warning:**  
After you click "Save", you must reboot the firewall to make the changes take effect. You may also have to do one or more of the following steps before you can access your firewall again:

- change the IP address of your computer
- renew its DHCP lease
- access the webGUI with the new IP address

Interfaces: Assign network ports

**!** The changes have been saved. You must reboot your firewall for changes to take effect.

Interface assignments VLANs

| Interface | Network port             |
|-----------|--------------------------|
| LAN       | sis0 (00:0d:b9:00:d9:24) |
| WAN       | sis1 (00:0d:b9:00:d9:25) |
| OPT1      | sis2 (00:0d:b9:00:d9:26) |

**+** < 1. Wireless Interface auswählen

**Save** < 2. Einstellungen sichern

**Warning:**  
After you click "Save", you must reboot the firewall to make the changes take effect. You may also have to do one or more of the following steps before you can access your firewall again:

- change the IP address of your computer
- renew its DHCP lease
- access the webGUI with the new IP address

Wireless < 3. Nun sollte das Wireless Interface sichtbar sein